



SAFEAERO

SERVICE AND MAINTENANCE INSTRUCTIONS

SAFEAERO TYPHOON

S/N 17523

Type	:Typhoon 16
Machine number	:16351
Year of construction	:2016 CE



CUSTERS HYDRAULICA B.V.

Smakterweg 33, 5804 AE Venray, the Netherlands
 P.O. Box 22, 5800 AA Venray, the Netherlands

Telephone: +31 (0) 478 553 000
 Fax : +31 (0) 478 553 010

ORIGINAL INSTRUCTIONS

SERVICE AND MAINTENANCE INSTRUCTIONS

CONTENTS

1. MAINTENANCE	3
2. SIMPLE FAULTS	9
3. OTHER.....	10
4. OPTIONAL EXTRAS	11
5. OVERVIEW OF THE STICKERS	12

APPENDICES:

Spare parts list

Hydraulic diagram (enclosed separately) no. 0116.601.111


Circuit diagram (enclosed separately) no. 0116.701.109/110

These service and maintenance instructions form an integral part of the de-icer and must always be kept with the machine so that it can be consulted whenever necessary. This handbook contains instructions of the service and maintenance of the SAFEAERO truck de-icer. Please refer to the manual provided by the vehicle manufacturer for the use and maintenance of the vehicle. Pictures and captions may contain general information and be intended for illustrative purpose; hence the specific deicer may vary.

1. MAINTENANCE

In order to keep the SAFEAERO de-icer in good working order and, through this, to ensure its safe and effective use, maintenance must be carried out at regular intervals.

Maintenance of the de-icer may only be carried out by trained and skilled professionals.




The maintenance of the de-icer consists of:

- Checking whether the de-icer functions correctly.
- Checking the de-icer for faults.
- Preventative maintenance, such as checking the oil level and making sure the moving parts work correctly.
- Corrective measures, such as replacing faulty components.
- Checking whether all the stickers containing instructions and warnings are in place and are still legible.

The de-icer must be maintained in accordance with the schedule shown below.

MAINTENANCE SCHEDULE	Daily	Weekly	Monthly	Yearly	Comment
Visual inspection	*				1
Check the oil level (when the de-icer is in the rest position)		*			
Check the vehicle's battery		*			2
Check the attachment of the rotating joint			*		3
Check the bolt attachment to the chassis			*		
Lubrication			*		4
Check the hoses			*		5
Lubricate the swing drive			*		6
Check the axle locks			*		
Check the hand pump			*		7
Check the switches			*		8
Grease locks of shutters				*	
Clean/replace the hydraulic system's filter				*	
Check the hydraulic oil				*	9

- Comment 1: During the visual inspection, attention must be given to:
- Damage/cracks (particularly to the welds). Check the welds for signs of fatigue. Rust and hairline cracks in a weld are a strong indication of fatigue. Every structural weld that is considered to be in a poor condition must be rectified and must never be ignored.
 - Deformation.
 - Rust.
 - Oil leaks.
 - Loose components.
 - Whether all the stickers containing instructions and warnings are in place and are still legible.
- Comment 2: Keep the vehicle's battery in a good condition. The good operation of the de-icer depends on the condition of the vehicle's battery.
- Comment 3: Make sure the bolts that fix the rotating joint into place are not loose. If necessary, tighten them.
- Comment 4: Spray the slide contacts (steel/steel or steel/slide plate) with a Teflon based lubricant. This concerns the extending and retracting components of the telescopic arm.
Slide the components to be lubricated out as far as possible and then spray the entire length of the sliding surfaces. Allow the lubricant enough time to take effect (a couple of hours) before sliding the components back in.
- Comment 5: Check the hoses (particularly the hoses in a hinged point) for kinks, wear and damage.
Hydraulic hoses must not be repaired. A hydraulic hose must always be replaced by a new, unused hose.
- Comment 6: Lubricate according to the instructions given below:




Lubricate with Molykote BR2 Plus

Lubricate with universal grease

- Comment 7: The hand pump must be kept operational (oiled and lubricated) and it must be tested to see whether it is in good working order.
- Comment 8: Visually check the limit switches and proximity switches and keep them free of dust, dirt, ice and snow.
- Comment 9: Contamination of the oil by solid particles, foreign liquids or water has a negative effect on the life span and the properties of the oil. Contamination may be the cause of faults and increased wear. Hydraulic oil has the tendency to age as a result of oxidization. In that case, there will be rubber-like deposits.
 The following method can be used to get an impression of the condition of the oil. Allow a drop of oil to fall onto filter paper. The oil will run and create a spot. If the oil is clean, then the spot will be even. If the oil is old, the spot will have a dark area in the middle as a result of the ageing products. Also check the colour of the oil. If it is white, then there is water in the oil.
 Therefore, the degree of contamination and ageing of the oil must be checked at regular intervals. Depending on the results, measures must be taken, such as:
- Filtering when solid, non-soluble contamination is found.
 - Separation when mixed with water.

- Changing the oil when it has aged or when the contamination can no longer be filtered out. When changing the oil, the hydraulic system must always be cleaned before the new oil is added to the system.



Oils, lubricants and grease to be used:

Hydraulic oil	According to ISO32
Grease for lubricating the swing drive brake	Molykote BR2 Plus
Grease for lubricating the hinged points	Assembly: Universal lithium based grease Maintenance: silicone spray
Grease for lubricating the gearing	Universal lithium based grease
Slide contacts (steel/steel or steel/plastic)	Teflon based lubricant
Grease for locks	Lockspray (silicone spray)

**THE DE-ICER HAS BEEN DESIGNED FOR A TOTAL OF 100,000 CYCLES (FOR EXAMPLE, 10 YEARS AT 50 WEEKS PER YEAR, 40 HOURS PER WEEK AND 5 CYCLES PER HOUR).
THE MACHINE MUST UNDERGO A TOTAL OVERHAUL AND INSPECTION BY THE MANUFACTURER WITHIN THE SPECIFIED NUMBER OF CYCLES AND NO LATER THAN AFTER 12 YEARS.
IN THE CASE OF INTENSIVE USE, THE OVERHAUL MUST BE CARRIED OUT EARLIER.**

As a result of the applicable legal regulations, the de-icer must undergo a periodic inspection (at least once a year) by an authorized inspector.

The periodic (annual) inspection is basically a visual and functional inspection and concerns:

- The condition of the components and safety devices, as well as checking whether any alterations have been made.
- Checking whether the safety devices are still complete and operational.

General information relating to this periodic inspection (not all the information may be applicable) can be found in the following table:

<i>Component to be inspected</i>	<i>Inspection points</i>
Type plate, text plates and inscriptions	Attachment, legibility, completeness
Maintenance and operating instructions	Condition, legibility
Logbook	Condition, legibility, correct use
Warning inscriptions	Condition, visibility
Protection against unauthorized use	Condition, function, operation
Operating instruments for - Lifting, lowering, swinging - Driving	Condition, function, operation, permanent indication of the direction of movement, protection against unauthorized operation
Emergency stop	Condition, function, operation
Equipment for communication purposes	Condition, function, observability, reliability
Equipment for a stable set-up - Levelling	Condition, function, operation, wear, deformation, corrosion, cracks, welds
Supporting components	Cracks, deformation, corrosion, operation and wear of guides, rollers, hinged points, bearings, attachment and locks of removable connections, operation of locks, welds
Basket/working platform - Railing - Base - Parallel guide rail - Step/ladder/entrance	- Condition, corrosion, deformation, attachment and locks of removable components, operation of locks, moveability of moving components, welds - Anti-slip, deformation, corrosion - Condition, function, wear, cracks, corrosion, welds - Anti-slip, deformation, corrosion, damage, attachment and locks of moveable components, welds
Chains/steel cables - Rollers/wheels - Tensioning device	Operation, wear, cracks, lock of the chain pins - Condition, function - Condition, function
Hydraulic system - Oil - Lines/connections - Hoses/connections - Cylinders - Filter - Pressure limiting valve	Oil leak, bleeding - Contamination/ageing/mixing with water, condition and legibility of dipstick/glass, quantity - Attachment, damage, deformation, corrosion - Attachment, damage, fragility, porosity - Attachment, cracks, welds, line and hose connections, seals, surface of piston rod (grooves), contamination - Condition - Condition
Driving drives - Service brake - Hand brake - Shaft lock	- Wear, operation - Wear, operation - Condition, operation
Other drives - Brakes, self-braking drives, connections	Connections of the drive components, running without knocks - Wear, operation
Electrical system - Lines/Pipes - Earth connections	- Damage, attachment, strain relief of loose pipes - Attachment, damage
Special safety devices, such as emergency limit switch, chain/cable switch, catch	Completeness, operation, attachment, condition, deformation, operation of the switching elements, contamination, condition of the (pressure) springs

2. SIMPLE FAULTS

Check the following first before searching for the cause of a fault:

- Are all emergency stop buttons reset (not pressed)? An emergency stop button is reset by turning it clockwise a quarter of a turn.
- Has the basket door been closed properly?
- Does the hydraulic system contain enough oil?

ELECTRICAL FAULT


- Check the fuses.
- Check whether the wiring on the switches and in the clamps is in place.

HYDRAULIC FAULT

- When, regardless of the position of the selector switch, the movement is always the same, the magnetic valve concerned has got stuck (e.g. as a result of dirt in the oil). This fault is usually solved by manually operating the valve a couple of times.
- If only the swinging movement is possible, then this is probably caused by a slide in the proportional valve being stuck. Clean the valve.

3. OTHER

- Dismantling the machine: before the machine is disassembled, the hydraulic oil must be removed from the hydraulic system and disposed of in accordance with the environmental regulations. Plastic and metal components must be separated. Have the machine disassembled by the manufacturer, the dealer or an authorized company.
- When moving the deicer over greater distances (for instance transport over public road) it is strongly recommended to fasten the upperarm to the support by means of 2 bolts.



4. OPTIONAL EXTRAS

*** START/STOP in combination with a START PROTECTION DEVICE**

With the START/STOP option, the vehicle's engine can be started and stopped from the basket.

The start protection device ensures that the vehicle cannot be started from the basket if the gearbox is not in neutral. The vehicle can also not be started if the engine is already running.

***AXLE LOCK**

It is only possible to use the de-icer if the rear axle has been locked.

The rear axle is automatically locked when the upper arm has been moved out of the transport position and is automatically unlocked again when the upper arm has been returned to the transport position.

If the axle is locked, all the de-icer movements are possible and it is also possible to drive the vehicle at a maximum speed of 6 km/h.

If the axle is unlocked, no de-icer movements are possible and it is possible to drive the vehicle at a speed greater than 6 km/h.


***BASKET DOOR SAFETY DEVICE**

Deicer movement is not possible, unless the basket door is closed.

Opening the basket door is impossible, if the basket is not in the rest position.

5. OVERVIEW OF THE STICKERS

Basket load (black on white)




Basket load (white on blue)




Toxic fluids (black on yellow)



Danger for trapping/shearing (black on yellow)



Attach belt (black on white)



Safety belt (black on yellow)

MAINTENANCE/EMERGENCY OPERATION ATTACH SAFETY BELT

Wheelforce (black on white)

MAX. WHEELFORCE 11000 kg


Pressure rear (black on white)

PRESSURE 5,75 BAR


Pressure front (black on white)

PRESSURE 7,0 BAR

Emergency operation (black on white)




Towing (black on white)





REGULATIONS FOR USE		number 16350
<ul style="list-style-type: none"> -the operator (minimum age 18) must know the contents of the use and operating regulations -max. load is 205 kg or 2 persons plus 45 kg; the maximum basket load must not be exceeded -do not use in a wind greater than wind force 8 Bft (20.6 m/s); max. permissible manual force: 300 N; max. tilt: 1,5° -always use the hand brake when working with the platform -only use on a horizontal, flat surface which is able to support the weight; if necessary, use bearing plates -driving at height only allowed on flat surface, free of obstacles, holes, kerbs -pay attention to the danger of becoming trapped, particularly near/under the basket -only enter/exit basket using intended entrance; it is not permitted to enter/exit basket whilst it is at a height -the operator must make sure that he or she does not put himself/herself or others in danger -there must not be any obstacles in the hydraulic platform's lifting range -the hydraulic platform must be used on a surface which will not affect the stability -it is prohibited to work on or near live (electric) components -it is prohibited to use the hydraulic platform as a hoisting crane -it is prohibited to leave the hydraulic platform whilst it is in extended position -it is forbidden to stand on the railing or to use ladders, scaffolding, etc. in the basket to gain extra height -it is prohibited to use protruding loads; it is prohibited to increase size of the basket or the basket's wind surface -avoid undesirable movements of the hydraulic platform's raised components during maintenance work 		
OPERATION		
PUTTING INTO OPERATION	<ul style="list-style-type: none"> -raise upper arm, until arm is free and until rear axle is locked -raise lower arm, until arm is free -every movement is now possible 	
RETURNING TO TRANSPORT POSITION	<ul style="list-style-type: none"> -retract telescopic arm -slew to longitudinal axis of vehicle -fully lower the bottom arm -lower the upper arm until it rests in support 	<p>Custers Hydraulic B.V. Smakterweg 33 5804AE Venray tel.: 0478 - 553000 www.custers.nl</p>
DRIVING AT HEIGHT	<ul style="list-style-type: none"> -take care of sufficient view on basket -maximum speed 6 km/h 	
PLACING BASKET HORIZONTAL	<ul style="list-style-type: none"> -turn basket correction button to desired position -activate with joystick 	EMERGENCY OPERATION
		always disengage P.T.O. first during emergency operation
		PLATFORM return to transport position as follows:
		-when the main drive fails: -operate the switch for the desired movement -move the joystick out of the neutral position -switch on the emergency pump -OR pump with handpump -for an electrical fault: -activate the bypass valve (when moving lower arm down or telescopic arm out) -activate the relevant magnetic valve -pump using the hand pump
		EMERGENCY OPERATION
		REAR AXLE return to transport position as follows:
		-PTO must be engaged -turn corresponding button to the right
		EM. LOWERING WITH BUTTON
		-pay attention for obstacles under lowering deicer -pull button lowering the bottom arm
		WARNING
		the safety devices will not work during emergency operation in case of an electrical fault; therefore only make movements in a safe direction


APPENDIX: Spare parts list





5	1	bump protection	7113110010
4	1	stairs	7100110255
3	1	basket	7100110240
2	1	de-icer elevator	7116012300
1	1	de-icer truck	7113410001
pos	qty	part	number











66	2	tiewrap plate	3100_ZB-IGUS
65	3	switch lever	4213100120-REF
64	3	switch head	4213100113-REF
63	3	switch body	4213100107-REF
62	2	switch	4212061020-REF
61	1	sensor	4212013125-REF
60	1	sensor	4212013084-REF
59	2	buffer	6405035508
58	12	lockplate	7901035053
57	18	lockplate	7901035043
56	2	shaft 50 x 570	7901151570
55	1	shaft 50 x 300	7901151300
54	1	shaft 50 x 230	7901151230
53	2	shaft 50 x 120	7901151120
52	3	shaft 40 x 380	7901141380
51	3	shaft 40 x 230	7901141230
50	1	shaft 40 x 140	7901141140
49	2	shaft 40 x 100	7901141100
48	2	bearing	6141505550
47	2	bearing	6141404430
46	14	bearing	6140505550
45	2	bearing	6140505550-37
44	6	bearing	6140505550-35
43	4	bearing	6140505550-18
42	12	bearing	6140404450
41	2	bearing	6140404450-35
40	8	bearing	6140404450-26
39	4	bearing	6140404450-18
38	8	bearing	6140404440
37	4	bearing	6140404430
36	1	cover	7100730223
35	1	block	7902910907
34	1	block	7902910903
33	1	sliding plate	7100222078
32	1	sliding plate	7100222051
31	1	sliding plate	7100222050
30	2	pin ø35	7100222012
29	4	pin ø24	7100222011
28	1	cover	7100222338
27	1	cover	7100222337
26	1	cover	7100222336
25	2	cover	7100222335
24	1	track 2 (De-Icer)	7116222317
23	1	track 1 (De-Icer)	7116222316
22	1	rack	7100400152
21	1	plate	7100730270
20	1	support	7112352012
19	1	sliding plate	7100412148
18	1	cylinder	7912050024
17	1	cage support	7100122300
16	1	level (2)	7100262305
15	1	level (1)	7100262300
14	1	parallelrod	7100261300
13	1	cylinder	7912125005
12	1	upperarm	7100212300
11	1	cylinder	7912070025
10	1	telescop arm 2	7116222310
9	1	cylinder	7912125004
8	1	cylinder	7912050023
7	1	support	7100222331
6	1	cover	7116222309
5	1	telescop arm1	7116222300
4	1	cover	7113312019
3	1	support	7113312001
2	1	turntable	7113312010
1	1	swiveldrive	5387000419
pos	qty	part	number





30	1	cover column	7113730011
29	1	cover column	7113730010
28	1	pump lever	7908010120
27	1	level	5750030000-REF
26	1	Waterpas	6411000100
25	1	side protection	7100882900
24	1	side protection	7100882810
23	1	side protection	7100881375
22	1	side protection	7100881305
21	1	side protection	7100881095
20	1	side protection	7100881075
19	4	support	7100870102
18	2	mudguard	SPATSC_DEICER
17	4	support	7100870128
16	1	support	7113870007
15	1	stairs	7113412004
14	1	stairs	7100870310
13	1	materialbox	7113870010
12	4	lock plate	7901035053
11	4	lock plate	7901035043
10	2	shaft	7901141090
9	8	bearing	6140505540-21
8	4	bearing	6140404450-22
7	4	bearing	6140404450-19
6	2	catch for hook	7113420060
5	2	cilinder	7912090025
4	2	hook	7113420050
3	1	sliding plate	7100412147
2	1	support up.arm	7113412030
1	1	frame	7113412010
pos	qty	part	number

*** END OF DOCUMENT ***